

Changing current language to communicate between non-English computers with WMicrotracker

Windows 7:


In Windows 7, open the *Control Panel* and click the "Clock, Language, and Region" link.



In the "Clock, Language, and Region" panel, click on *Region and Language*.



This opens the *Region and Language* window. There, go to the *Administrative* tab. In the "*Language for non-Unicode programs*" section, you can see the currently set language. To change it, first click on *Change system locale*.



You should select "English (United States)"

Restart Computer after changes


Windows XP:

1. Go to Control Panel (the desktop version)
2. Clock, Language, and Region.
3. Region.
4. Click on the Administrative tab on the top.
5. Under Language for non-Unicode programs, select the button Change system locale , then select "English" display language.
6. Restart your computer.

WINDOWS 10


Instruction for NON-UNICODE programs language change

1) Go to windows text bar and search “Regional”




2) Open “regional config” menu


3) From the right menu, select “additional options for regional configuration”




4) Click Region “change date,time format”



5) Go to “Administrative tools”



6) Change the language for non Unicode p rograms to “English (USA)” and **Deselect the checkbox** (Beta Version: use UTF-8)



7) Restart the computer